



Figure 1





A



B

Figure 2






Where:


- 1 = pathogen
- 2 = ligand
- 3 = receptor
- 4 = microsphere
- 5 = liquid crystal molecule

Figure 3

Sample will be processed and concentrated
before being applied to detector.

Figure 4






Where:

1	=	chamber containing antibody
2	=	mixing causway
2a	=	baffles designed to induce mixing
3	=	chamber containing microspheres
4	=	chamber containing liquid crystal
5	=	laminar flow causway
6	=	detection chamber


Figure 5



Where:

- 1 = syringe barrel
- 2 = syringe plunger
- 3 = sample
- 4 = male leur
- 5 = female leur
- 6 = cassette wall
- 7 = sample expelled into cassette
- 8 = side ports in valve assembly
- 9 = valve plug
- 10 = spring

Figure 6




where:

- 1 = mixing causway
- 2 = blister pack containing antibody
- 3 = blister pack wall segment designed to rupture when pressurized
- 4 = baffel designed to induce mixing
- 5 = blister pack containing microspheres
- 6 = blister pack containing liquid crystal
- 7 = laminar flow causway
- 8 = detection chamber

Figure 7


Detection Chamber



where:

- 1** = chamber side wall of cassette construction material (foreground wall removed for clarity)
- 2** = transparent plate exhibiting low birefringence
- 3** = plate surface treated to interact with and align liquid crystal with longitudinal axis of chamber (bottom arrow)


Figure 8



where:

- 1 = light source
- 2 = director polarizer aligned with the longitudinal
axis of the detection chamber
- 3 = low birefringence plates whose surface
treatment aligns the liquid Crystal with the
director orientation
- 4 = analyser polarizer aligned perpendicular to the
longitudinal axis of the chamber
- 5 = light detector

Figure 9




The reader device moves the roller up until it compresses the sample chamber. Between each chamber and mixing pathway is a thin walls that ruptures as the sample is forced down the flow & mixing channel as the roller slowly moves to the right. In progressive sequence, antibody, anti-antibody-coated microspheres and liquid crystal are added to and mixed with the sample. The roller stops when the mixed sample is delivered to the reader chamber.

Each sample is a potential biohazard. Thus, samples are applied through an one-way valve and the cassette is completely enclosed.

Figure 10

reader chamber (polyimid-coated, non-birefringent glass)



The reader device moves the roller up until it compresses the sample chamber. The sample is forced down the flow & mixing channel as the roller slowly moves to the right. In progressive sequence, antibody, anti-antibody-coated microspheres and liquid crystal are added to and mixed with the sample. The roller stops when the mixed sample is delivered to the reader chamber.

Each sample is a potential biohazard. Thus, samples are applied through an one-way valve and the cassette is completely enclosed.

Figure 11




Figure 12




Figure 13




Figure 14





Figure 15

BEST AVAILABLE COPY

Figure 16






Figure 17

BEST AVAILABLE COPY